AIRFIELD NAME		September 25					EGNX	Central	
CALLSIGN		East Midlands					124.005		
CALLSIGN		EGNX_TWR					Ground 121.905		
LOCATION		Lat N052.49.52.000 Long W001.19.40.000					Elev. 306Ft.		
LOCATION GEO.		7nm SE of Derby					App. Dir. 120.130		
CHART SOURCE		NATS <b>Listening SSR within 20nm</b> ; See chart below. No service. SW.				VFR Conspicuity 4573			
METAR	EGNX 122.680 (EGBB)Squawk			0010: N. Squawk 4572 Normally, no service			QFE=QNH -10 HPscls.		
NAV AIDS	NDB.	EMW. OM 0	9. 393.00				RADAR 126.180		
RUNWAY	Nam	Name Size Surface NORDO A/C. PPR Before departure.							
	09 / 27   2894m x 45m (59m)   Asphalt   The Runway has 7M shoulders, & 30							•	
AIRSPACE		Class D EGNX CTR/CTA Transition Altitude A6000ft Airspace above Class A.FL105.Davntry CTA							
CIRCUITS	1000ft QFE, A1300. Jet/Turboprop, MIN A2000ft As directed, normally SOUTH, SOUTH OF DISEWORTH								
NO FLY	Northern Circuits to be <b>NORTH of CASTLE DONINGTON</b> . Avoid KEGWORTH (Turning finals for R27).								
	Also avoid the villages of ASTON and WESTON-ON-TRENT. ALL circuit Training PPR required								
LOCAL HAZARDS	BIRDS- Various, on surrounding farmland. ATC may delay A/C to allow Bird Dispersal operations.								
	2 wind turbines West of Maintenance Area South, within the Perimeter road can cause turbulence								
	across the runway with strong southerly winds. Caution multiple lines of grid lines around the area								
	especially East/West, within the ATZ								
HELICOPTER OPERATIONS	Helicopters should expect to arrive / depart EGNX using the low level lanes, as VFR A/C, landing /								
	departing via the Active runway, or as instructed by ATC. Arriving A/C should expect (RUNWAY 27) to								
	vacate via M; H or G. (Runway 09) via S; W or A. Unless otherwise instructed. Taxi route will then be								
SPECIAL		stated. Departing A/C will be given taxi route and Runway entry instructions. Confused? ASK FOR HELP  THE LOW LEVEL LANES. The lanes are intended for use by VFR A/C during IMC conditions, with an SVFR							
RULES									
KOLLS	approval. VFR A/C may also use the lanes to transit N/S; S/N. ATC may delay these flights if there is VFR								
	traffic in / out of EGNX. VISUAL CIRCUITS: 1. Pilots shall avoid making a final turn onto R27 over								
	KEGWORTH.								
	If YOU want to use the lanes then route inbound via Trowel for (Long Eaton) or Markfield for								
	(Shepshed).								
	OTHER INBOUNDS. If you do not want the lanes, or ATC is controlling you, then you will be told (Flt. Plan								
	it) to report at one of the VRPs and most likely follow one of the routes shown below. If given specific								
	heading and heights, make sure you maintain them. You will be part of ATC's traffic plan.								
	BASIC	BASIC Circuit information. 1. Hold 1000ft QFE, unless instructed by ATC.							
	2. All circuits to the SOUTH, <b>MUST keep clear of and SOUTH of DISEWORTH</b> .								
	3. ALL circuits to the NORTH, <b>MUST keep clear of and NORTH of CASTLE DONINGTON</b> .								
	4. Pilots will also keep clear of <b>ASTON and WESTON on TRENT</b> , 2nm NW of the aerodrome.								
	VFR OUTBOUNDS. Using the LANES. Study the diagram, Very simply DO NOT CROSS THE MOTORWAY.								
	Report as requested or leaving the zone at SHEPSHED or LONG EATON.								
		ATC Departures. Via VRPs. If you flt. plan your vrp, ATC will try to oblige.							
	Expect to be directed to leave the zone AT RIGHT ANGLES TO THE RUNWAY. You will the be given the								
	route to your VRP – or as instructed.								
	VFR FIXED wing pilots are reminded that prompt vacation of the runway will assist ATC traffic								
REMARKS	handling. – Vacate using Sierra or Mike, or as instructed. Land long to minimise time on runway.								
	CIX flights of 1-3 A/C should use the RVL Apron; Group flights as below.								
	Inbound: request Donnair apron (maintenance are North). Outbound: State position to Ground as								
	"Donnair apron, Maintenance area North."								
	CIX VFR CLUB A/C please note (virtual) arrangements have been made for our group flights to use the								
	Donair apron. Request it when calling Ground for your taxi instructions via HOLD M4. (see chart								
		below)							
1		*							





