AIRFIELD NAME			May 24	BE\	/ERLEY, LINLEY HILL	EGNY	North
CALLSIGN (A/C RADIO)			Beverley Radio			123.050	
CALLSIGN (ES/VATSIM)			EGNY_R_TWR			Ground	
LOCATION			Lat No53.53.90.000		Long W000.21.68.000	Elev. 5ft	
LOCATION GEOGRAPHIC			4nm NNE of Beverly			VFR Conspicuity	
CHART SOURCE FSX /		PlanG4	NO NORDO A/C, UNLESS PPR BEFORE DEPARTURE		QFE= QNH		
METAR AIRPORT EGNJ		124.130 Beverly is an unlicensed A/F. PPR required for all visits					
NAV AIDS	NO	Beverly operates both Fixed Wing and Microlight Training. All helicopters, hover taxi.					
RUNWAY	Headings		Dimension Surface		ALL Pilots using runway 12 MUST have VISUAL CONTACT		
	12 / 30		710m x 30m Grass		with the POWER LINES BEFORE starting FINAL approach.		
AIRSPACE	CLASS G		Transition level 3000ft		CAUTION Wind Turbines, (4 x 3 rows),350ft AGL 1nm South		
CIRCUITS Mandatory Overhead join. NOT below A2000ft AGL. All circuits to the North. See circuit diagrams.							
NO FLY AREAS NEV		NEVER:	/ER: Leven and Brandesburton. Avoid bird sanctuary 1.5 nm NW of A/F.				
LOCAL B		BIRDS: POWER LINES to west of A/F, WITHIN THE CIRCUITS. Drainage Dyke North Edge of A/F,					
HAZARDS		ALSO along SE edge of A/F. Noise Abatement requires Rwy. 12 departures to turn 90° on T/O					
HELICOPTERS		As Microlight circuit, 'H' shown for convenience of Sim pilots, no information, RW.					
SPECIAL RULES		If there is a Fixed Wing / GA A/c late downwind; on base or finals, MICROLIGHT MUST GIVE WAY.					



